

LEAD-FREE TERMINATION INDICATOR -- "e3" LOCATION ON COMPONENTS

PACKAGE STYLE/TYPE	LOCATION OF Pb Free Designator	COMMENTS	PACKAGE STYLE/TYPE	LOCATION OF Pb Free Designator	COMMENTS
DC - 2X2 DFN	Rearrange Trace Code		N, NW	"e3" After Trace code	
DD - 3x3 DFN	Replace Pin1 Indicator with "<"		N8	"e3" After Datecode	
DD - 3x3 DFN	Replace Pin1 Indicator with "<"		P	"e3" After Trace code	PbSn die attach internal
DDB - 3x2 DFN	Rearrange Trace Code		Q	"e3" After Trace code	PbSn die attach internal
DE - 4x3 DFN	Replace Pin1 Indicator with "<"		R	"e3" After Trace code	PbSn die attach internal
DH - 5x5 DFN	Replace Pin1 Indicator with "<"		S14	"e3" After Datecode	
DHC - 5x3 DFN	Replace Pin1 Indicator with "<"		S16	"e3" After Datecode	
DHD - 5x4 DFN	Replace Pin1 Indicator with "<"		S3	Replace Pin1 Indicator with "<"	
F14	"e3" After Datecode		S4	Replace Pin1 Indicator with "<"	
F20	"e3" After Datecode		S5	Replace Pin1 Indicator with "<"	
FE-16	"e3" After Trace code		S6	Replace Pin1 Indicator with "<"	
FE-20	"e3" After Trace code		S8	"e3" After Datecode	
FE-28	"e3" After Trace code		SC6	Replace Pin1 Indicator with "<"	
FW48	"e3" After Trace code		ST	"e3" After Datecode	PbSn die attach internal
FW56	"e3" After Trace code		SW16	"e3" After Trace code	
G16	"e3" After Datecode		SW18	"e3" After Trace code	
G20	"e3" After Trace code		SW20	"e3" After Trace code	
G24	"e3" After Trace code		SW24	"e3" After Trace code	
G28	"e3" After Trace code		SW28	"e3" After Trace code	
G36	"e3" After Trace code		T	"e3" After Trace code	PbSn die attach internal
GN16	"e3" After Datecode		T7	"e3" After Trace code	PbSn die attach internal
GN20	"e3" After Datecode		TS8	Replace Pin1 Indicator with "<"	
GN24	"e3" After Datecode		UD - 3x3 QFN	Replace Pin1 Indicator with "<"	
GN28	"e3" After Datecode		UE - 4x3 DFN	Replace Pin1 Indicator with "<"	
GW36	"e3" After Trace code		UF - 4x4 QFN	Replace Pin1 Indicator with "<"	
GW44	"e3" After Trace code		UH - 5x5 QFN	Replace Pin1 Indicator with "<"	
M	"e3" After Trace code	PbSn die attach internal	UHF - 5x7 QFN	Replace Pin1 Indicator with "<"	
MS	"e3" On Third Line		UK - 7x7 QFN	"e3" After Trace code	
MS8	"e3" On Third Line		UP - 9x9 QFN	"e3" After Trace code	
MS8E	"e3" On Third Line		Z	"e3" After Datecode	
MSE	"e3" On Third Line				