

LT1994

Low Noise, Low Distortion, Fully Differential Amplifier/Driver

DESCRIPTION

Demonstration circuit 961 features an LT1994, low noise, low distortion, fully differential amplifier. The LT1994 is a high precision, very low noise, low distortion, fully differential input/output amplifier (see Table 1). The LT1994's output common mode voltage is independent of the input common mode voltage, and is adjustable by applying a voltage on the V_{OCM} pin. The DC961 board contains an LT1994 amplifier configured as a unity gain differential amplifier with 499Ω feedback and input resistors. Gains greater than one require changing the input resistors to a value lower than 499Ω (refer to Figure 2). In addition, DC961 has surface-mount pads and traces for resistors and capacitors for building first and second order fully differential filter circuits. The differential outputs of DC961 can be configured with a first order RC network for driving the differential inputs of an Analog to Digital Converter (ADC).

Connection to the differential input and output of a DC961 is through SMA connectors. On board jumpers configure the DC961 for dual or single power supply operation. The differential input of a DC961 is AC coupled with 1μF capacitors for ease of use as a dual or a single supply circuit. DC coupling to the DC961 input is provided through the shorting of the input capacitors with zero ohm surface-mount resistor jumpers. In addition, the DC961 has surface-mount pads to add input passive components for input signal filtering and DC biasing.

Design files for this circuit board are available.

Call the LTC factory.

LT, LTC and LT are registered trademarks of Linear Technology Corporation.

Figure 1. DC961A





Table 1. LT1994 Noise and Distortion


Differential Input Referred Voltage Noise Density	3nV/rtHz
Distortion, 2Vp-p Differential Input, V _s =3V, f _{in} =1MHz, R _{load} =800Ω	
2 nd Harmonic	99dBc
3 rd Harmonic	96dBc

Figure 2. Typical Application for an LT1994



QUICK TEST PROCEDURE

Figure 3. Single-Ended Input To Differential Output Quick Test Set-Up



A. Single-Ended Input To Differential Output

1. Connect to a DC961 a dual power supply, a function generator and an oscilloscope as shown in Figure 3 (JP1 to PWR_ON, JP2 to DUAL and JP3 to INT).

Note 1: The 50 ohm termination on J2 input is used to balance the 50 ohm generator impedance on J1 input. The additional 50 ohm input impedance is in series with the 499 ohm input impedance of the LT1994 therefore the single-ended to differential gain is equal to 0.909 ($[499/(499+50)]$).

2. Set the function generator for a 1Vp-p, 100 kHz sine-wave and turn-on the power supply.

3. The channel 2 input of the oscilloscope is in phase with the DC961 input and the channel 1 input is 180 degrees out of phase with the DC961 input. The single-


ended output shown on channel 1 or 2 is a 0.4545Vp-p sinewave (a 0.909Vp-p differential output).

Note 2: The LT1994 can directly drive at least a 25pF capacitive load at each output. However the LT1994 can drive directly a low frequency sinewave (100 kHz or less) into a capacitive load of up to 100pF. In this "Quick Test" procedure, the output signal is a sinewave and each LT1994 output drives the capacitance of a 24 inch or less cable plus the input capacitance of the oscilloscope input, a capacitive load of 70pF (30pF per foot for the coax cable and 10pF for the oscilloscope input). For testing the transient response of the LT1994 to a square-wave or a pulse, use a 10x low capacitance oscilloscope probe to monitor the DC961 output at J3 or J4.

B. DC Coupled Inputs and Output Common Mode Voltage Adjustment

1. On the DC961, install 0603 zero ohm resistors at R1 and R10 to short input capacitors C8 and C12 respectively (see DC961 schematic).
2. Connect DC961 as shown in Figure 4 (JP1 to PWR_ON, JP2 to SINGLE, and JP3 to EXT VOCM).
3. Apply an input signal with a DC offset (V_{inCM}) 0V to $V_+ - 1.25V$. The output common mode (VOCM) can be set independently of the V_{inCM} from 1.1V to $V_+ - 0.8V$. This adjustment is made by applying a DC voltage at EXT VOCM.

Figure 4. Input and Output Common Mode Quick Test Set-Up




C. Driving the Analog Inputs of an ADC

When using a DC961 to drive the differential input of an ADC (analog-to-digital converter), the boards output resistors R12 and R15 and capacitors C18, C21 and C22 should be configured to the values required for the ADC input. Figure 5 shows the optimum values for the DC961 output components when driving an ADC.

LTC2202 and LTC2203 is a 16-bit 10Msps and 25Msps ADC respectively and LTC2245 and LTC2246 is a 14-bit 10Msps and 25Msps ADC respectively

Figure 5. DC961 Output Component Values



D. Using a DC961 to Implement a Fully Differential, Second Order Lowpass Filter.

Figure 6. A DC961 configured as a second order lowpass filter.





Figure 6. Fully differential, 2nd order, lowpass filter design schematic (from LT1994 data sheet).



Design Procedure

The following procedure is from the LT1994 data sheet. The design schematic resistor and capacitor designators have the following correspondence with the DC961 resistor and capacitor designators:

Design Schematic	DC961
R11	Z1
R21	R3
R31	R9
C11	C11
C21	C5
C22	C6
R12	Z2
R22	R7
R32	R8

Differential 2nd Order Butterworth Lowpass Filter

$$f_{3dB} \leq 2.5\text{MHz and Gain} \leq 8.8 \text{ or } \text{Gain} \leq \frac{2.5\text{MHz}}{f_{3dB}}$$

Component Calculation:

$R11 = R12$, $R21 = R22$, $R31 = R32$, $C21 = C22$, $C11 = 10 \cdot C21$, $R1 = R11$, $R2 = R21$, $R3 = R31$, $C2 = C21$ and $C1 = C11$

1. Calculate an absolute value for C2 ($C2_{abs}$) using a specified -3dB frequency

$$C2_{abs} = \frac{4 \cdot 10^5}{f_{3dB}} \quad (C2_{abs} \text{ in pF and } f_{3dB} \text{ in kHz})$$

2. Select a standard 5% capacitor value nearest the absolute value for C2 ($C1 = 10 \cdot C2$)


3. Calculate R3, R2 and R1 using the standard 5% C2 value, the specified f_{3dB} and the specified passband gain (Gn)

R1, R2 and R3 equations ($C2$ in pF and f_{3dB} in kHz)

$$R3 = \frac{(1.121 - \sqrt{(1.131 - 0.127 \cdot Gn)}) \cdot 10^8}{(Gn + 1) \cdot C2 \cdot f_{3dB}}$$

$$R2 = \frac{1.266 \cdot 10^{15}}{R3 \cdot C2^2 \cdot f_{3dB}^2} \quad R1 = \frac{R2}{Gn}$$

NOTES : unless otherwise specified



LTC CONFIDENTIAL - FOR CUSTOMER USE ONLY

Customer Notice

Linear Technology Has Made A Best Effort To Design A Circuit That Meets Customer-Supplied Specifications. However, It Remains The Customer's Responsibility To Verify Proper And Reliable Operation In The Actual Application. Component Substitution And Printed Circuit Board Layout May Significantly Affect Circuit Performance Or Reliability. Contact Linear Technology Applications Engineering For Assistance.

This Circuit Is Proprietary To Linear Technology And Supplied For Use With Linear Technology Parts.

LINEAR TECHNOLOGY CORPORATION

1630 MCCARTHY BLVD.
MILL PITAS, CA 95035
PHONE (408) 432-1900 FAX (408) 434-0507

Fully Differential Amplifier

Size Document Number
DC961A LT1994CMT8

Rev